PRODUCT USAGE QUICK GUIDE

Ultra Disinfectant

Cleaning and disinfection of hard surfaces and key touch points





Cleanline Ultra Disinfectant is a high performance disinfectant with broad spectrum activity against bacteria, yeast and viruses.

AVAILABLE UNIT SIZE(S) & CODES:

CL1058 - 750ml RTU CL4059 - 5 Litre Eco-Refill



Always wear Personal Protective Equipment (PPE) when handling, dispensing and using chemicals.



Refer to the Safety Data Sheet (SDS) for detailed information and immediate first aid measures including medical emergency helpline number.



Use appropriate PPE as indicated in the safety data sheet.



Re-apply the solution to the surface/ equipment and allow contact time.



Kills 99.99% of the most common forms of bacteria and viruses. Conforms to protocols EN 1276 (inc. MRSA), EN 14476 and EN 16777.



Remove any visible dirt and gross contamination from the surface before cleaning.



Apply the solution to a cloth or spray and wipe to clean the surface/ equipment.



CLAIM	EN TEST PROTOCOL	CONTACT TIME
Bactericidal	EN 1276:2019 (inc. MRSA)	30 sec.
	EN 13697 (inc. <i>E. coli</i>)	5 min.
Yeasticidal	EN 16615	1 min.
Virucidal	EN 14476:2013 +A1:2015 (inc. Influenza A (H1N1) Virus)	5 min.
	BS EN 14476:2013+A2:2019 (Feline coronavirus)	1 min.
	EN 16777:2018 (Feline Coronavirus)	1 min.

To disinfect the surface and to meet the requirements of EN 1276, EN 14476 and EN 16777 for broad-spectrum activity against bacteria and viruses, allow 60 seconds contact time.



Rinse cloth in clean water, wring out and wipe surface*. Allow to air dry.



*Rinse the surface with clean water removes any disinfectant residue from food contact surfaces in kitchens and food preparation equipment and prevents subsequent skin contact with the product (e.g. Work station surfaces where hand and arms might rest for extended periods).

